Point to point connection between PG/PC with STARTER and MICROMASTER 4 drives.



Please note:

- -Check that the hardware is set up correctly. The connecting cable must be securely connected at both ends.
- The orange and green LEDs on the BOP-link should be lit permanently to indicate an error-free state
- The COM interface selected depends on the computer hardware (on a Field PG with I-Box the COM2 must be selected).
- The automatic detection of the baud rate will not always work if the baud rate has been changed from the factory settings.
- The use of the BOP or AOP is recommended to perform a quick and easy check on the parameter settings (communication) on the drive side.

Hints if STARTER cannot establish an online connection with a MICROMASTER 4xx drive



First possibility: Insert drive in project automatically



Drive

Second possibility: Insert drive into project manually and then make an online connection Drive



Address can be selected or entered here. (also the same addresses in one project are possible).

Second possibility to get the drive address via STARTER



Drive

	A 055 network diagnostics
Access Path	Automatic Slave Recognition
Access Point of the Application:	Bus node
S70NLINE (STEP 7) → PC COM-Port (USS)	0 1 2 3 4 5 6 7 8 9
(Standard for STEP 7)	
PC COM-Port (USS) Properties	
CP5511(PPI) Diagnostics	
BISO Ind. Ethernet→ Intel(R) PRO/Wireles BISO Ind. Ethernet→ Realtek RTL8139/81 BIPC COM-Port (USS)	30
	Test-slaves
(Parameterizing your PC COM port for a USS protocol)	
Interfaces	
Add/Remove: Select	
OK Cancel Help	
	OK Abbrechen Hilfe

Second possibility (error case 1): If address is different, you can get a solution as follow:



Second possibility (error case 2): If drive version is different, you can get a solution as follow:

