



AGC 150

Basic knowledge



Synchronizing Controllers



GPC-3
Base mounted
Non-Power Management



AGC 200
Front mounted
Standard Power Management




AGC-4
Base mounted
Custom Power Management



AGC 150
Front mounted
Simple Power Management

Documentation

www.deif.com contains all manuals for the controllers



Maximise your business

Award-winning global supplier of innovative power management solutions, engine & genset controllers, switchboard equipment, marine bridge instrumentation and renewable energy control solutions.

Documentation

English

About Contact Career Software Support Training Webinars Whitepapers Publications Documentation

DEIF

Land Power Marine & Offshore Wind Power

Products / AGC 150

AGC 150

AGC 150 - Advanced Genset Controller

The AGC 150 is a genset controller containing all necessary functions for control and protection of a genset. The slim design makes the controller suitable for paralleling even small gensets thus the AGC 150 is integrable in nearly all types of gensets.

Pages

[WEBINAR: AGC 150 Produktvorstellung](#) - [WEBINAR: AGC 150](#)

Subsegments


[INDUSTRY: First-mover in hybrid microgrid solutions](#) - [INDUSTRY: Naval vessels](#) - [INDUSTRY: Hydro](#)

Description Features Videos & Media **Documentation**

Documents

- + Brochures/Handouts
- + Data Sheet
- + Designer's Handbook
- + Installation Instructions
- + Operator's Manual

AGC 150




AUTO

SEMI AUTO

Shortcut Menu

DG BLOCKED FOR START
Jump
Mode
Test
Lamp test

AGC 150



GOV / AVR

-10... 10VDC

PWM

USB

Ethernet TCP/IP

RS485 (2)


RS485 (1)

Additional I/O

ECU

DEIF PMS

Typical wiring



Basic Settings

Setup Current Transformer

The image shows the DEIF software interface for configuring a 3-phase CT. The left sidebar contains navigation options: Advanced Protection, Parameters, and I/O. The main window is titled "3 phase CT" and is divided into "G Primary I" and "G Secondary I" sections.

G Primary I
Description: Generator current transformer value primary side
Set point: 1000 A (5 .. 9000)

G Secondary I
Description: Generator current transformer value secondary side
Set point: 1A (dropdown menu with options 1A, 1A, 5A)

The wiring diagram below illustrates the connection between a generator (G) and a transformer. The primary side (P1, P2) is connected to the generator's L1, L2, and L3 phases. The secondary side (S1, S2) is connected to the transformer's primary terminals. The transformer's secondary terminals are connected to the generator's L1, L2, and L3 phases. The diagram also shows the connection of a 3-phase CT (P1, P2, S1, S2) to the generator's L1, L2, and L3 phases. A "Configurable CT" is highlighted in blue, indicating its connection to the generator's L1, L2, and L3 phases.

The terminal block at the bottom is labeled with the following connections:

Terminal	Connection
56	L1 (s1)
57	L2 (s1)
58	L3 (s1)
59	Com (s2)
60	L4 (s1)
61	L4 (s2)
62	N
63	L1
64	L2
65	L3
8	DC (+)
9	Out
10	Out
11	Out
12	Out
13	Out
14	Out
15	MB on
16	MB off
17	GB/TB on
18	GB/TB off
39	In
40	In
41	In
42	In
43	In
44	In
45	In
46	In
47	MB on
48	MB off
49	GB/TB on
50	GB/TB off
66	N
67	L1
68	L2
69	L3
	USB

Basic Settings

Nominal settings

The image displays the DEIF software interface for configuring a 3-phase nominal power set point. The interface is divided into a left sidebar with navigation options (Advanced Protection, Parameters, I/O) and a main area showing the configuration tree and a detailed parameter view.

Configuration Tree (Left):

- Basic settings
 - Application type
 - Measurement setup
 - Nominal settings
 - Voltage
 - Generator nominal U
 - Busbar nominal U
 - Current
 - 3 phase nominal
 - 4th CT nominal
 - Frequency
 - Power
 - 3 phase nominal (highlighted in red)
 - 4th CT nominal
 - RPM

Parameter View (Right):

- View mode: Tree List
- 3 phase nominal
- Nom. P 1
- Description: Nominal generator power set point 1
- Set point: 480 kW (10 .. 20000)

Electrical Schematic (Bottom):

The schematic diagram illustrates the power flow from a generator (G) through a busbar system to a load. Key components include:

- Generator (G) connected to a busbar with phases L1, L2, L3, and N.
- Current Transformers (CT) labeled P1, P2, s1, s2 for each phase, with a note "Configurable CT" pointing to the CT connections.
- Busbar (GB) and Motor (MB) connected to the busbar.
- Control relays K1 and K2, and fuses F3, F4, F5.
- Terminal block connections for AC current CT-side (56-61), AC voltage A-side (62-65), DC output (8-18), Digital input (39-50), and AC voltage B-side (66-69).

Terminal	Label
56	L1 (s1)
57	L2 (s1)
58	L3 (s1)
59	Com (s2)
60	L4 (s1)
61	L4 (s2)
62	N
63	L1
64	L2
65	L3
8	DC (+)
9	Out
10	Out
11	Out
12	Out
13	Out
14	Out
15	MB on
16	MB off
17	GB/TB on
18	GB/TB off
39	In
40	In
41	In
42	In
43	In
44	In
45	In
46	In
47	In
48	MB on
49	MB off
50	GB/TB on
66	N
67	L1
68	L2
69	L3


Start Sequence

1. Before starting, **start prepare** ON (Relay 9). Can be used to activate pre-heating element.
If not required, timer can be changed to 0s to reduce starting time.
2. Shortly after, **Starter/crank** (relay 6) and **Run coil** (relay 5), both ON.
Once running feedback detected, **Starter/crank** is deactivated.
3. **Run coil** activates continuously all the time, for the duration of engine running.



Glow plug

starting
running



I/O settings


Inputs Outputs

Relay 5
I/O number / function Run coil

Relay 6
I/O number / function Starter (Crank)

Relay 9
I/O number / function Start prepare

Relay 10
I/O number / function Stop coil



View mode: Tree List

DEIF

Basic settings
Communication
Engine
Running detection
Start sequence
Before crank
Start prepare
Run coil
Start threshold
Crank
Crank failure
Start failure
Start attempts
Crank timers
After crank
Idle run
Warm up ramp
Stop sequence
Gov

View mode: Tree List

Start Prepare

Start On Time
Description: Setup of Starter ON time during cranking.
Timer: 5 sec (1 .. 600)

Start Off Time
Description: Setup of Starter OFF time before a new start attempt is made
Timer: 5 sec (1 .. 99)

Generator Protection

Checkmark [✓] = enable

The screenshot displays the DEIF software interface for generator protection configuration. On the left is a navigation tree with categories like Device, Alarms, Trending, Advanced Protection, and Parameters. The 'Parameters' section is expanded to show 'Generator' settings, including AC configuration, AVR, Voltage protections, Current protections, Frequency protections, and Power protections. The 'Reverse power' option under Power protections is highlighted. The main area shows a list of protection functions: Over-voltage, Over-current, Earth fault inverse time over-current, Over-frequency, Under-frequency, and Reverse power. Two reverse power protection levels are detailed below:

- P> 1**
 - Description: Reverse power protection level 1 (ANSI 32)
 - Set point: -5 % (-200 .. 0)
 - Timer: 10 sec (0.1 .. 100)
 - Failclass: Trip GB
- P> 2**
 - Description: Reverse power protection level 2 (ANSI 32)
 - Set point: -5 % (-200 .. 0)
 - Timer: 10 sec (0.1 .. 100)
 - Failclass: Trip GB

Each protection level has a grey square, an edit icon, and a star icon to its right.

And many more

Generator Protection

Fail class:



Trip + stop = GB trip, engine stop after cooling down

Safety stop = Extra genset start up & replace faulty genset

Trip MB/GB = In application “Single DG with mains”, will trip MB instead

I/O

DIGITAL INPUT

DIGITAL OUTPUT

ANALOG INPUT





Digital Input

12 digital inputs, activated by negative (-) VDC signal

Each can be configured as:

1. **Alarms** setup by Display or USW
2. **Function** setup by USW only



Digital Input

1. Digital input as **alarm**

Parameter > I/O settings > Inputs > *Digital inputs*

The screenshot shows the DEIF parameter configuration interface. The left sidebar contains navigation icons for Device, Alarms, Trending, and Advanced Protection, with the Parameters icon selected. The main area is titled "Digital input" and shows settings for three digital inputs: 39, 40, and 41. Input 39 is enabled (checkbox checked) and has a timer of 10 seconds and a failclass of Warning. Input 40 is disabled (checkbox unchecked) and has a timer of 10 seconds and a failclass of Warning. Input 41 is disabled (checkbox unchecked) and has a timer of 10 seconds and a failclass of Warning. A dropdown menu is open for the failclass of input 40, showing options: Warning, Trip GB, Trip+stop, Shutdown, Trip MB, Safety stop, Trip MB/GB, and Controlled stop. Green callout boxes highlight the "[√] to enable" checkbox for input 39, the "Set delay" timer field for input 39, and the "Action" dropdown menu for input 40.

View mode: Tree List

DEIF

Basic settings
Communication
Engine
Generator
Busbar
Mains
Breakers
Synchronisation
Power set points
Power management
I/O settings
 Inputs
 Digital input
 Outputs
 External I/O
Functions
Alternative configuration
USW specific parameters

Digital input 39

Description: Setup of digital input on terminal 39

Timer: 10 sec (0 .. 100)

Failclass: Warning

Digital input 40

Description: Setup of digital input on terminal 40

Timer: 10 sec (0 .. 100)

Failclass: Warning

Digital input 41

Description: Setup of digital input on terminal 41

Timer: 10 sec (0 .. 100)

Failclass: Warning

[√] to enable



Set delay

Action

Digital Input

2. Digital input as Function

Click icon *I/O settings*



Digital Input

Default assignment



Terminal no.	Function	Remarks
39	Auto start/stop	For remote start signal
40	Not used	
41	Not used	
42	Not used	
43	Not used	
44	Not used	
45	Not used	
46	Not used	
47	Status MB ON	For application with Mains
48	Status MB OFF	For application with Mains
49	Status GB ON	
50	Status GB OFF	

Digital Output

12 digital outputs (DC outputs)

Require common positive (+) VDC



Configuration by USW



Digital Output

Setup digital output

Click icon *I/O settings*



Digital output

Default assignment:

Terminal no.	Function	Remarks
4	Common (+) for DO 5-6	Also serves as Emergency stop
5	Run coil	
6	Starter (crank)	
-----	-----	-----
8	Common (+) for DO 9-18	
9	Start prepare	
10	Stop coil	
11	Status OK	
12	Horn	
13	Not used	
14	Not used	
15	MB ON	For application with Mains
16	MB OFF	For application with Mains
17	GB ON	
18	GB OFF	

Analog Input

Configuring multi inputs

DEIF

Advanced Protection

Parameters

Inputs/Outputs

Multi Input

Options

Logs

Translations

Input 20 | Input 21 | Input 22 | Input 23

Input type: RMI oil pressure

Scaling: 1/10

Selected curve

Configurable curve

	Input	Output
Set point 1	10	40
Set point 2	44.9	50
Set point 3	81	60
Set point 4	134.7	80
Set point 5	184	100
Set point 6	200	110
Set point 7	210	115
Set point 8	220	120

RMI type: Configurable (Bar/celsius)

Select RMI Type

- Configurable
- Oil pres. type 1 (bar)
- Oil pres. type 2 (bar)
- Oil pres. type 4 (bar)

1st Alarm

Alarm when input is: High

Set point: 5

Delay: 10 Sec.

Fail class: Warning

Output A: Not used

Output B: Not used

Auto acknowledge: OFF

Inhibits: Inhibits...

2nd Alarm

Alarm when input is: Disable

Set point: 5

Delay: 10 Sec.

Fail class: Warning

Output A: Not used

Output B: Not used

Auto acknowledge: OFF

Inhibits: Inhibits...

Input & Output Text




To change text, use **Translations**

The screenshot shows the DEIF software interface with a 'Find' dialog box open. The dialog is titled 'Find' and contains the text 'Search on "Master language"'. The 'Find what:' field contains 'digital input'. There are checkboxes for 'Case sensitive', 'From start', and 'Exact search', all of which are currently unchecked. The 'Find next' button is highlighted with a blue border. The background shows a table with columns for 'Status', 'Master language', and 'Language'. The table lists digital inputs from 39 to 48. Digital input 40 is highlighted in blue, and its value 'ENGINE FAULT' is highlighted in green.

Status	Master language	Language
	Relay 13	Relay 13
	Relay 14	Relay 14
	Relay 15	Relay 15
	Relay 16	Relay 16
	Relay 17	Relay 17
	Relay 18	Relay 18
	Digital input 39	Digital input 39
	Digital input 40	ENGINE FAULT
	Digital input 41	Digital input 41
	Digital input 42	Digital input 42
	Digital input 43	Digital input 43
	Digital input 44	Digital input 44
	Digital input 45	Digital input 45
	Digital input 46	Digital input 46
	Digital input 47	Digital input 47
	Digital input 48	Digital input 48

Input & Output Status



Any digital input/output can be monitored through USW and display



Analog Regulation

SPEED REGULATION - ANALOG

VOLTAGE REGULATION - ANALOG




Speed Regulation - Analog

1. Setup terminal analog output

Parameter > Engine > Gov > *General configuration*


The screenshot shows the DEIF software interface with the 'General configuration' window open for the 'Reg. output GOV' parameter. The 'Set point' dropdown is set to 'Analogue', and the 'Output A' dropdown is set to 'Transducer 52'. A 'Parameter "Reg. output GOV" (Channel 2781)' dialog box is also visible, showing the 'Analogue' set point and 'service' password level. Green arrows point from the 'Analogue' and 'Transducer 52' selections to the dialog box and a terminal diagram respectively.



Speed Regulation - Analog

2. Setting analog output range (VDC)

Parameter > Engine > Gov > General configuration > **AOUT 52 limits**



View mode: Tree List

DEIF



- > Basic settings
- > Communication
- > Engine
 - > Running detection
 - > Start sequence
 - > Stop sequence
 - > Gov
 - > General configuration
 - AOUT 52 limits**
 - PWM 52 setup
 - > Relay configuration
 - > EIC configuration
 - > Speed PID
 - Manuel step
 - Offset for control signal
 - Regulation failure
 - > Battery/Aux supply
 - > Protections
 - > Maintenance
 - Shutdown Override
- > Generator

AOUT 52 limits

AOUT 52 Gov Type
Description: Setup of analog out 52 for governor type
Set point: Adjustable

AOUT 52 Limits
Description: Minimum limit for analogue output 52
Set point: -10 V (-10.5 .. 5)

AOUT 52 Limits
Description: Maximum limit for analogue output 52
Set point: 10 V (-5 .. 10.5)



Speed Regulation - Analog

3. Setting offset / center

Parameter > Engine > Gov > *Offset for control signal*

The screenshot shows the DEIF control interface. On the left is a navigation menu with icons for Device, Alarms, Trending, and Advanced Protection. The main area displays a tree view of parameters under 'Engine' > 'Gov'. The 'Offset for control signal' parameter is selected and highlighted. The right pane shows the configuration for 'GOV output offset 1', including a description and a slider set to 50%.



View mode: Tree List

Offset for control signal

GOV output offset 1

Description: Offset of the analogue output used for governor regulation set point 1

Set point: % (0 .. 100)




Speed Regulation – Analog Gain

1. PID Island

Parameter > Engine > Gov > Speed PID

> *Island (analog/EIC)*



The screenshot shows the DEIF control interface. The left sidebar contains navigation icons for Device, Alarms, Trending, and Advanced Protection. The main area displays the configuration for the 'Island (analog/EIC)' parameter. The configuration is organized into three sections: f Kp, f Ti, and f Td.


Parameter	Description	Set point	Range
f Kp	Proportional gain value of the PID controller for frequency regulation	2.5	(0 .. 60)
f Ti	Integral time value of the PID controller for frequency regulation	1.5 s	s (0 .. 60)
f Td	Differential time value of the PID controller for frequency regulation	0	s (0 .. 2)

Speed Regulation – Analog Gain

2. PID Load sharing

Parameter > Engine > Gov > Speed PID

> Load share (analog/EIC)



DEIF

View mode: Tree List

- > Basic settings
- > Communication
- ▼ Engine
 - > Running detection
 - > Start sequence
 - > Stop sequence
 - ▼ Gov
 - > General configuration
 - > Relay configuration
 - > EIC configuration
 - ▼ Speed PID
 - Island (analog/EIC)
 - Island (relay)
 - Load share (analog/EIC)**
 - Load share (relay)
 - Mains parallel (analog/EIC)
 - Mains parallel (relay)
 - Manuel step
 - Offset for control signal
 - Regulation failure

Load share (analog/EIC)

P loadsh. f Kp

Description: Proportional gain value of the PID controller for load sharing

Set point: (0 .. 60)

P loadsh. f Ti

Description: Integral time value of the PID controller for load sharing

Set point: s (0 .. 60)

P loadsh. f Td

Description: Differential time value of the PID controller for load sharing


Set point: s (0 .. 2)

Speed Regulation – Analog Gain

3. PID Mains parallel

Parameter > Engine > Gov > Speed PID

> *Mains parallel (analog/EIC)*



The screenshot shows the DEIF control interface. The left sidebar contains navigation icons for Device, Alarms, Trending, and Advanced Protection. The main area displays the configuration for 'Mains parallel (analog/EIC)' under the 'Speed PID' section. The configuration includes three parameters: P Kp, P Ti, and P Td.

Parameter	Description	Set point	Range
P Kp	Proportional gain value of the PID controller for power regulation	2.5	(0 .. 60)
P Ti	Integral time value of the PID controller for power regulation	1.5 s	(0 .. 60)
P Td	Differential time value of the PID controller for power regulation	0 s	(0 .. 2)

Voltage Regulation - Analog

1. Setup terminal analog output

Parameter > Generator > AVR > *General configuration*

The screenshot displays the DEIF software interface for configuring the AVR (Automatic Voltage Regulator) output. The left sidebar shows the navigation tree with 'Parameters' selected. The main area shows the 'General configuration' for 'Reg. output AVR' and 'AVR output'. A 'Parameter "Reg. output AVR" (Channel 2782)' dialog box is open, showing the 'Set point' set to 'Analogue' and 'Password level' set to 'service'. The 'AVR output' section shows 'Output A' set to 'Transducer 55'. A blue box labeled 'More setting' is visible. Below the interface, a terminal block diagram shows terminals 47-61. A blue box highlights terminals 54 and 55, which are labeled 'AVR (-)' and 'AVR (+)' respectively. The diagram also shows terminals 51 and 52 labeled 'GOV (-)' and 'GOV (+)', and terminal 53 labeled 'Not used'. The terminals are arranged in two rows: 47-50 and 51-60 on the top row, and 47-50 and 56-61 on the bottom row.

47	48	49	50	51	52	53	54	55	56	57	58	59	60	
47	48	49	50	51	52	53	54	55	56	57	58	59	60	61
				GOV (-)	GOV (+)	Not used	AVR (-)	AVR (+)						
Analogue output														

Voltage Regulation - Analog

2. Setting analog output range & center

Parameter > Generator > AVR > General configuration > [AOUT 55 limits](#)


Parameter > Generator > AVR > [Offset for control signal](#)

The screenshot shows the DEIF parameter configuration interface for 'AOUT 55 Limits'. The left sidebar contains navigation icons for Device, Alarms, Trending, and Parameters. The main panel is titled 'AOUT 55 Limits' and shows the following configuration:

- View mode:** Tree (selected), List
- Navigation:** Basic settings, Communication, Engine, Generator > AC configuration > AVR > General configuration > AOUT 55 Limits
- AOUT 55 AVR Type:**
 - Description: Setup of analog out 55 for AVR type
 - Set point: Adjustable
- AOUT 55 Limits:**
 - Description: Minimum limit for analogue output 55
 - Set point: -10 V (-10.5 .. 5)

The screenshot shows the DEIF parameter configuration interface for 'Offset for control signal'. The left sidebar contains navigation icons for Device, Alarms, Trending, and Parameters. The main panel is titled 'Offset for control signal' and shows the following configuration:

- View mode:** Tree (selected), List
- Navigation:** Basic settings, Communication, Engine, Generator > AC configuration > AVR > General configuration > Offset for control signal
- AVR output offset 1:**
 - Description: Offset of the analogue output used for AVR regulation set point 1
 - Set point: 50 % (0 .. 100)



Voltage Regulation – Analog Gain

Same principle with speed PID

Parameter > Generator > AVR > Voltage PID >

- Island (analog/EIC)
- Load share (analog/EIC)
- Mains parallel (analog/EIC)


The screenshot displays the DEIF control software interface. On the left is a navigation sidebar with icons for Device, Alarms, Trending, and Advanced Protection. The main area shows a tree view of the configuration menu. The path 'Generator > AVR > Voltage PID' is expanded, and three sub-parameters are highlighted: 'Island (analog/EIC)', 'Load share (analog/EIC)', and 'Mains parallel (analog/EIC)'. Three overlapping windows are shown, each displaying the configuration for one of these parameters. The 'Island (analog/EIC)' window shows the 'U Kp' parameter. The 'Load share (analog/EIC)' window shows the 'Q loadsh. U Kp' parameter. The 'Mains parallel (analog/EIC)' window shows three parameters: 'Q Kp' (Proportional gain value of the PID controller for reactive power regulation, set point 2.5), 'Q Ti' (Integral time value of the PID controller for reactive power regulation, set point 1.5 s), and 'Q Td' (Differential time value of the PID controller for reactive power regulation, set point 0 s).

Analog Regulation Status

Check **Device**

> Governor reg.


> AVR reg.



Relay regulation

SPEED REGULATION - RELAY

VOLTAGE REGULATION - RELAY



Speed Regulation - Relay

1. Change Gov setting to relay

Parameter > Engine > Gov > *General configuration*

The screenshot shows the DEIF control interface. On the left is a navigation menu with icons for Device, Alarms, Trending, and Advanced. The main area is titled 'General configuration' and contains the following settings:


- Reg. output GOV**
 - Description: Selection of regulation output used for governor regulation
 - Set point: **EIC** (dropdown menu is open showing options: EIC, **Relay**, Analogue, EIC)
- Governor output**
 - Description: Transducer selection number in case of analogue output for the speed governor
 - Output A: **Disabled** (dropdown menu)

Annotations on the screenshot include a green arrow pointing to the 'Relay' option in the dropdown menu with the text 'Select "Relay"', and a grey arrow pointing to the 'Disabled' dropdown menu with the text 'ignore this part..'.

Speed Regulation - Relay

2. Setup pulse signal and choosing relay terminals

Parameter > Engine > Gov > Relay configuration > *Output and period*



The screenshot shows the DEIF control software interface. The left sidebar contains navigation icons for Device, Alarms, Trending, and Advanced Protection. The main area is titled 'Output and period' and contains two configuration sections:

- GOV ON time:** Description: The min. ON time of the relay outputs used for governor relay regulation. Set point: 500 ms (10 .. 6500).
- GOV period time:** Description: The regulator period time used for governor relay regulation. Set point: 2500 ms (250 .. 32500).

Below these sections, there are two dropdown menus for 'Output A' and 'Output B'. 'Output A' is currently set to 'Terminal 13' and 'Output B' is set to 'Terminal 14'. A red box highlights these dropdowns, with red arrows pointing to them and the text 'Increase' and 'Decrease' respectively. A red box at the bottom contains the text 'Select any unused DO'.

Speed Regulation - Relay

3. Setup speed Gain

Parameter > Engine > Gov > Speed PID >

□ Island (relay)

□ Load share (relay)

□ Mains Parallel (relay)

The screenshot displays the DEIF control interface. On the left, there is a sidebar with icons for 'Device', 'Alarms', and 'Trending'. The main area shows a tree view of parameters under 'Engine > Gov > Speed PID'. Three panels are overlaid on the interface, each showing the configuration for a specific relay:


- Island (relay)**: Shows 'f deadband'.
- Load share (relay)**: Shows 'P L S f deadband'.
- Mains parallel (relay)**: Shows 'P deadband' and 'P Kp relay'.

The 'Mains parallel (relay)' panel details are as follows:

- P deadband**: Description: Deadband of the controller for frequency regulation. Set point: 2 % (0.2 .. 10).
- P Kp relay**: Description: Proportional gain value of the controller for frequency regulation. Set point: 10 (0 .. 100).

Speed Regulation - Relay

Regulation Deadband



Voltage Regulation - Relay

1. Change AVR setting to relay


Parameter > Generator > AVR > *General configuration*

The screenshot displays the DEIF control interface. On the left is a navigation menu with icons for Device, Alarms, Trending, and Advanced. The main area shows the 'General configuration' page for the AVR. The 'Reg. output AVR' section has a description 'Selection of regulation output used for AVR regulation' and a 'Set point' dropdown menu. The dropdown menu is open, showing options: EIC, Relay, Analogue, and EIC. A blue arrow points to the 'Relay' option with the text 'Select "Relay"'. The 'AVR output' section has a description 'Transducer selection number in case of analogue output for the voltage regulator' and an 'Output A' dropdown menu set to 'Transducer 55'. A grey arrow points to the 'Output A' dropdown menu with the text 'ignore this setting'.

Voltage Regulation - Relay

2. Setup pulse signal and choosing relay terminals

Parameter > Generator > AVR > Relay configuration > *Output and period*



View mode: Tree List

DEIF

- > Basic settings
- > Communication
- > Engine
- > Generator
 - > AC configuration
 - > AVR
 - > General configuration
 - > Relay configuration
 - Output and period**
 - > DAVR configuration
 - > Voltage PID
 - Manuel step
 - Offset for control signal
 - Regulation failure
 - > DAVR configuration
 - > Voltage PID
 - Manuel step
 - Offset for control signal
 - Regulation failure
 - > Voltage protections
 - > Current protections
 - > Frequency protections
 - > Power protections
 - > Reactive power protections
- > Busbar
- > Mains
- > Breakers
- > Synchronisation
- > Power set points
- > Power management

Output and period

AVR ON time

Description: Min. ON time of the relay outputs for AVR regulation

Set point: 100 ms (10 .. 3000)

AVR period time

Description: AVR duty cycle time

Set point: 500 ms (50 .. 15000)

Output A: Not used → Relay Increase

Output B: Not used → Relay Decrease

Select any unused DO

Voltage Regulation - Relay

3. Setup voltage Gain

Parameter > Generator > AVR > Voltage PID >

- Island (relay)
- Load share (relay)
- Mains Parallel (relay)

When commissioning, set deadband to minimum to check genset response
After completed, set deadband back to prolong relay lifetime

The screenshot displays the DEIF control software interface. On the left, a navigation tree shows the hierarchy: Basic settings, Communication, Engine, Generator, AC configuration, AVR, and Voltage PID. The 'Voltage PID' section is expanded, showing 'Island (relay)', 'Load share (relay)', and 'Mains parallel (relay)'. The main area shows three panels for these relays:


- Island (relay)**: Shows 'Q L S U deadband' with a description: 'Deadband of the voltage regulation in load sharing'.
- Load share (relay)**: Shows 'Q deadband' with a description: 'Deadband of the controller for reactive power regulation' and a set point of 2% (0..10).
- Mains parallel (relay)**: Shows 'Q Kp relay' with a description: 'Proportional gain value for the reactive power regulation' and a set point of 10 (0..100).

Relay Regulation Status


Check **Device**

> Governor reg.

> AVR reg.




Synchronisation



Synchronisation

AGC always perform synchronism check before closing breakers

All modes: Auto, Semi Auto, and Manual



Genset should run slightly faster than bus to avoid reverse power ($f_{gen} > f_{bus}$)

Allowed maximum slip frequency: **0.3Hz**



Synchronisation

Change slip frequency & voltage

Synchronisation > Dynamic synchronisation

The screenshot shows the DEIF software interface. On the left is a navigation tree with categories: Basic settings, Communication, Engine, Generator, Busbar, Mains, Breakers, and Synchronisation. Under Synchronisation, the following options are listed: Synchronisation type, Dynamic synchronisation (highlighted), Synchronisation regulator, Static synchronisation, Synchronisation failure, and CBE (Close before excitation). The main panel is titled 'Dynamic synchronisation' and contains two sections: 'Slip Frequency' (highlighted in green) and 'Slip Voltage'. The 'Slip Frequency' section includes 'Sync. dfMax' with a description 'Max. allowable frequency difference for Dynamic synchronisation' and a set point of 0.3 Hz (range 0..0.5), and 'Sync. dfMin' with a description 'Min. allowable frequency difference for Dynamic synchronisation' and a set point of 0 Hz (range -0.5..0.3).

Here, to sync with 50.0Hz 400V busbar, genset need to run:

- Freq between 50.0 – 50.3Hz
- Voltage between 380 – 420V

The screenshot shows the 'Slip Voltage' section of the DEIF software interface, highlighted in green. It contains two sections: 'Sync. dUMax' with a description 'Max. allowable voltage difference for Dynamic synchronisation' and a set point of 5 % (range 2..10), and 'Sync. dUMin' with a description 'Max. allowable value the regulated voltage must be below voltage to sync to' and a set point of -5 % (range -10..0).

Normally no need changing these settings

Application


SINGLE GENSET

MULTIPLE GENSETS



Typical Applications for AGC 150

- Single Genset
- Single Genset with Mains
- Multiple Genset's with Mains




Application

SINGLE GENSET

Single Genset

- Application configuration
- New plant configuration



Single Genset with Mains

The screenshot shows the DEIF software interface for configuring an application. The main window is titled "Application 1: Standard plant". On the left, there is a sidebar with the DEIF logo and several icons: a checkmark, a globe, and a gear. The "Application configuration" icon is highlighted with a green arrow. The main area is divided into "Area control" and "Area configuration - Top". Under "Area configuration - Top", the "Source" dropdown is set to "Mains", and the "ID" dropdown is set to "Mains". A green arrow points to the "Mains" option in the "Source" dropdown. Below this, the "Bottom" section has "Source" set to "Diesel gen", "ID" set to "0", and "GB" set to "Pulse". A "Plant options" dialog box is open on the right, showing "Product type" as "AGC 150 DG" and "Plant type" as "Single DG". A green arrow points to the "Single DG" option in the "Plant type" dropdown. The dialog box also has "Application emulation" set to "Off".

Single Genset



Alternative setup:*

Access from AGC 150 display:

Settings > Basic settings > Application type > Standalone or PM >

Application select > Active Application

Use active application from [1] to [2]




*Only works if application 2 in default factory setting

Single Genset

Select Genset Mode

Parameter > Basic settings > Application type > Genset type > *Genset/plant mode*



The screenshot shows the DEIF control interface. The left sidebar contains navigation icons for Device, Alarms, Trending, Advanced Protection, and Parameters. The main area is titled 'Genset/plant mode' and shows a tree view of settings. The 'Genset/plant mode' option is selected, and its configuration is displayed on the right. The 'Set point' dropdown menu is open, showing options: Island operation, Auto, Mains Failure (highlighted), Peak shaving, Fixed Power, Mains Power Export, Load take over, Power management, and Dry alternator. A green arrow points to the 'Auto, Mains Failure' option with the text 'Example: AMF'.

View mode: Tree List

DEIF

Basic settings

- Application type
 - Genset type
 - Genset/plant mode**
 - Measurement setup
 - Nominal settings
 - Controller settings
 - Communication
 - Engine
 - Generator
 - Busbar
 - Mains
 - Breakers
 - Synchronisation
 - Power set points
 - Power management
 - VO settings
 - Functions
 - Alternative configuration
 - USW specific parameters

Genset/plant mode

Genset Mode

Description: Generator running mode


Set point: **Auto, Mains Failure**

Example: AMF

Single Genset

Enable Back Synchronising

Parameter > Synchronisation > *Mains parallel settings*



The screenshot shows the DEIF control interface. The left sidebar contains navigation icons for Device, Alarms, Trending, and a gear icon. The main area displays a tree view of settings under 'Synchronisation', with 'Mains parallel settings' selected. The right pane shows the configuration for 'Mains parallel settings', including 'Back Synchronising' (checked) and 'Sync. to mains' (checked). A green arrow points to the 'Back Synchronising' checkbox.

View mode: Tree List

DEIF

Device

Alarms

Trending

- > Basic settings
- > Communication
- > Engine
- > Generator
- > Busbar
- > Mains
- > Breakers
- ▼ Synchronisation
 - Synchronisation type
 - Dynamic synchronisation
 - Synchronisation regulator
 - > Static synchronisation
 - > Synchronisation failure
 - > CBE (Close before excitation)
 - Angle offset
 - **Mains parallel settings**
 - Mains synchronisation inhibit
 - Deadbus closing

Mains parallel settings

Back Synchronising

Description: synchronising ON/OFF


Sync. to mains

Description: Allow synchronising MB

Single Genset

AMF delay settings

Parameter > Mains > AMF function > *AMF timer*



Navigation menu:

- > Basic settings
- > Communication
- > Engine
- > Generator
- > Busbar
- ▼ Mains
 - > Protections
 - Overlap
 - > Voltage and frequency limits
 - ▼ AMF functions
 - Start sequence ib AMF mode
 - AMF timer
- > Breakers
- > Synchronisation
- > Power set points
- > Power management
- > I/O settings
- > Functions
- > Alternative configuration
- > USW specific parameters

AMF timer

U mains failure

Description: Timer for mains failure voltage detection

Timer: 5 sec (0.5 .. 990) **Mains failure delay**

Mains OK Delay U

Description: Timer for mains voltage ok detection

Timer: 60 sec (2 .. 9900) **Mains Ok delay**

f mains failure

Description: Timer for mains failure frequency detection

Timer: 5 sec (0.5 .. 990)

Mains OK Delay f

Description: Timer for mains frequency ok detection

Timer: 60 sec (2 .. 9900)

Modeshift


Description: Allow switch to AMF mode

Set point: **Modeshift ON:** Other modes retain AMF function when Mains fail

Single Genset

Mains failure voltage setpoint

Parameter > Mains > Voltage and frequency limits > Voltage limits



The screenshot shows the DEIF control interface. The left sidebar contains the DEIF logo and three icons: a speedometer for 'Device', a warning triangle for 'Alarms', and a line graph for 'Alarms'. The main area is titled 'Voltage settings' and shows the following configuration:



- View mode:** Tree (selected), List
- Navigation tree:**
 - > Basic settings
 - > Communication
 - > Engine
 - > Generator
 - > Busbar
 - ▼ Mains
 - > Protections
 - Overlap
 - ▼ Voltage and frequency limits
 - Voltage settings (selected)
 - Frequency settings
 - > AMF functions
 - > Breakers
 - > Synchronisation

- Low Voltage settings:**
- Description: set point for mains voltage range low
- Set point: 90 % (30 .. 100)
- High Voltage settings:**
- Description: set point for mains voltage range high
- Set point: 110 % (100 .. 120)

Single Genset

Or **Device**

For detailed monitoring




Application

MULTIPLE GENSETS

Multiple Gensets

- Application configuration
- New plant configuration



File Connection Parameters Help

Area control Plant totals

Area 1 of 1

Area configuration - Top

Source None

ID 0

Bottom

Source Diesel gen

ID 0

Redundant controller

GB Pulse

< Add Delete Add >

Not connected

Plant options

Product AGC 15 "Standard"

Plant type Standard

Standard

Single DG

Gen-set group

Name:

Bus Tie options

Wrap bus bar

Power management CAN

Primary CAN

Secondary CAN

Primary and Secondary CAN

CAN bus off (stand-alone application)

Application emulation

Off

Breaker and engine cmd. active


Breaker and engine cmd. inactive

OK Cancel

Multiple Gensets

Select Genset Mode

Parameter > Basic settings > Application type > Genset type > *Genset/plant mode*




The screenshot shows the DEIF control interface. The left sidebar contains navigation icons for Device, Alarms, Trending, Advanced Protection, and Parameters. The main area is titled 'Genset/plant mode' and shows a tree view of settings. The 'Genset/plant mode' option is selected. The right pane displays the 'Genset Mode' configuration, with a dropdown menu open for the 'Set point' parameter. The dropdown menu lists several options: Power management, Auto. Mains Failure, Peak shaving, Fixed Power, Mains Power Export, Load take over, Power management (highlighted), Dry alternator, and Ventilation. A blue arrow points to the highlighted 'Power management' option with the text 'select power management'.

Multiple Gensets

Setup ID Number

Parameter > Communication > *Power management ID*



The screenshot shows the DEIF control interface. The left sidebar contains the DEIF logo and navigation icons for Device, Alarms, Trending, and a gear icon. The main area is titled 'Power management ID' and shows the configuration for the 'Int. comm. ID'. The 'Description' is 'Internal communication ID number' and the 'Set point' is a slider set to 1, with a range of (1 .. 32). A blue callout box with the text 'add ID on every genset' is overlaid on the interface.

View mode: Tree List

- > Basic settings
- ▼ Communication
 - Power management ID
 - > RS485
 - > CAN protocols
 - > Ethernet comm. error
- > Engine
- > Generator
- > Busbar
- > Mains
- > Breakers
- > Synchronisation
- > Power set points
- > Power management
- > I/O settings
- > Functions
- > Alternative configuration
- > USW specific parameters

Power management ID

Int. comm. ID


Description: Internal communication ID number

Set point: 1 (1 .. 32)

add ID on every genset


Multiple Gensets

CANbus wiring



Multiple Gensets

Check [Application Supervision](#)



DEIF utility software - 3.45.0; Connected to "AGC 150 DG" (version 1.00.0 rev. 2617)

File Connection Parameters Help

DEIF

Device

Application supervision

Alarms

Trending

Color legend

-Gen-sets-

- NotRunning Ready to autostart
- NotRunning Not ready to autostart
- Running Hz/V blackout
- Running Hz/V Ok
- Running Hz/V not Ok

-Symbols-

- Alarm
- No info

Emulation

GB1 GB2

G1 G2


Communication active Connected to "AGC 150 DG" (version 1.00.0 rev. 2617) COM3 (ID 1)

Incorrect communication
will be shown

Power Management

LOAD DEPENDENT START/STOP


MULTI START



Load dependent start/stop

Configure Start/stop based on load Percentage

Parameter > Power management > *Load dependent start/stop configuration*




The screenshot shows the DEIF control interface. On the left is a navigation tree with the following items: Basic settings, Communication, Engine, Generator, Busbar, Mains, Breakers, Synchronisation, Power set points, and Power management. Under 'Power management', 'Load dependent Start/stop configuration' is selected. The main panel is titled 'Load dependent Start/stop' and contains two sections: 'Ld. start/stop unit' and 'Ld. start/stop type'. The 'Ld. start/stop unit' section has a description: 'Selection of either kW or kVA for calculation of the Load dependent Start and Stop values' and a 'Set point' dropdown menu currently set to 'kW'. The 'Ld. start/stop type' section has a description: 'Selection of either Percentage or Value for calculation of the Load dependent Start and Stop values' and a 'Set point' dropdown menu with three options: 'Value', 'Value', and 'Percentage'. A green arrow points to the 'Percentage' option with the text 'Set as Percentage'.

Load dependent start/stop

Start percentage setpoint

Parameter > Power management > *Load dependent start 1*



Advanced Protection

Parameters

- > Basic settings
- > Communication
- > Engine
- > Generator
- > Busbar
- > Mains
- > Breakers
- > Synchronisation
- > Power set points
- ▼ Power management
 - Start/stop for Island
 - Easy connect
 - Load dependent Start/stop configuration
 - Load dependent start 1**
 - Load dependent start 2
 - Load dependent stop 1
 - Load dependent stop 2
 - Multi start set
 - > Priority
 - Available power
 - Communication failures
 - Busbar alarms
 - Additional power management settings
- > VO settings
- > Functions
- > Alternative configuration
- > USW specific parameters

Inputs/Outputs

Multi Input

Options

Load dependent start 1

Ld. start limit P

Description: Setting for Load dependent Start in kW

Set point: kW (1 .. 20000)

Ld. start limit S

Description: Setting for Load dependent Start in kVA

Set point: kVA (1 .. 20000)

Ld. start limit %

Description: Setting for Load dependent Start in Percentage

Set point: % (1 .. 100)

Ld. start timer


Description: Setup of Load dependent Start limits **Start delay**

Timer: sec (0 .. 990)

Load dependent start/stop

Stop percentage setpoint

Parameter > Power management > *Load dependent stop 1*



Advanced Protection

Parameters

- > Basic settings
- > Communication
- > Engine
- > Generator
- > Busbar
- > Mains
- > Breakers
- > Synchronisation
- > Power set points
- > Power management
 - Start/stop for island
 - Easy connect
 - Load dependent Start/stop configuration
 - Load dependent start 1
 - Load dependent start 2
 - Load dependent stop 1**
 - Load dependent stop 2
 - Multi start set
 - > Priority
 - Available power
 - Communication failures
 - Busbar alarms
 - Additional power management settings
- > I/O settings
- > Functions
- > Alternative configuration
- > USW specific parameters

Load dependent stop 1

Ld. stop limit P
Description: Setting for Load dependent Stop in kW
Set point: 200 kW (1 .. 20000)

Ld. stop limit S
Description: Setting for Load dependent Stop in kVA
Set point: 200 kVA (1 .. 20000)

Ld. stop limit %
Description: Setting for Load dependent Stop in Percentage % capacity after 1 genset removed
Set point: 70 % (1 .. 100)

Ld. stop timer
Description: Setup of Load dependent Stop limits Stopping delay
Timer: 30 sec (5 .. 990)

Multi start

Setup of how many gensets start together

Parameter > Power management > *Multi start set*

The diagram on the left shows two gensets, Genset 1 and Genset 2, connected to a common busbar. An 'Autostart/stop input' is connected to the busbar. Each genset has a 'Start' button. The middle screenshot shows the 'Parameters' menu with 'Multi start set' selected. The right screenshot shows the 'Multi start set' configuration page. The 'Set point' dropdown is open, showing options: 'Auto calculation', 'Start 1 DG', 'Start 2 DG', 'Start 3 DG', 'Start 4 DG', 'Start 5 DG', 'Start 6 DG', and 'Start 7 DG'. A blue arrow points to 'Start 2 DG' with the text 'Select Start 2 DG'. The 'Min. run. set 1' section shows a 'Set point' of '1' (range 0..32). The 'Multistart conf' section shows a 'Set point' of 'Multi start set 1'.

Questions?



/DEIFgroup



/company/DEIFgroup



/DEIF_group



/DEIFgroup



www.deif.com

Thank you



/DEIFgroup



/company/DEIFgroup



/DEIF_group



/DEIFgroup



www.deif.com