

# PEGATRON

Lucid Disassembly SOP

## Agenda

# • Lucid Disassembly SOP

- Front Case Disassembly
- System Disassembly
- Key Part Assembly




# Front Case Disassembly




2

Remove  
Screw



1


Remove  
warranty  
sticker







Open front  
case  
about 45°


# System Disassembly




Flip cover





Pull up







**Remove  
screw and  
Conductive  
fabric**




**Remove  
screw**





**Remove  
screw and  
Conductive  
fabrie**




**Remove  
screw and  
Conductive  
fabrie**









# Key Part Disassembly





Remove  
Battery  
connector



Remove key part before requirement remove battery connector for safety.

## SSD Key Part Disassembly



SSD

Remove  
screw



# 3G/GPS Key Part Disassembly

Remove screw and antenna

3G/GPS Combo



Take up

PEGATRON

Thanks

PEGATRON