



#### Advanced Manufacturing Research Centre















# Science and Manufacturing: Ingredients for Innovation

Professor Alma Hodzic

AMRC Research Director

17<sup>th</sup> December 2013

AFOSR, Washington DC











### Self-ameliorating inkjet printed composites for higher survivability

Programme Managers: Dr Lee "Les" Byung-Lip, Sc. D. and Lt Col Randall "Ty" Pollak, PhD

Yi Zhang ME

Andrew Cartledge ME



Hannah Crunkhorn **AMRC** 

PhD Candidates

IJ printing & IJPC analysis

Fatigue tests & FEA

Machining & characterisation

Research Fellows

Dr Jonathan Stringer, ME



Dr Richard Grainger, AMRC



Patrick Smith, ME



Alma Hodzic, AMRC



Christophe Pinna, ME



Richard Scaife, AMRC

**Supervisors** 














### Benefits of Inkjet Printing


- Direct write technology (no masks needed)
- Additive technology
- Droplets of ink ejected from a nozzle to pattern substrate
- Computer-aided which can pre-define patterns according to requirements
  - Rapid changing between patterns (no down-time)
- Non-contact deposition method (reduces/removes risk of contamination)














1 < Z < 10

Optimu

## Effect of Z on Droplet Volume



 $\frac{\mathbf{printing}_{\text{Re}}}{\mathbf{We}} = \frac{(\gamma \rho^{2})^{1/2}}{\eta}$ 

Droplet volume increases Z as predicted by Fromm

$$Z = (d\rho\gamma)^{1/2} / \mu$$

Droplet volume is normalised to the volume displaced by the actuator at different driving voltages

Reis, Derby J. Appl. Phys. 2005, 97, 094903


By varying the ink's rheology (viscosity or surface tension), we can vary the size of the ejected droplet








#### Influence of Voltage on Droplet Volume



Reis, Derby, J. Appl. Phys. 2005, 97, 094903

By varying voltage, we can vary the size of the ejected droplet Applied voltage is proportional to droplet volume

Increased Voltage =
Increased Droplet Volume





www.sheffieldcomposites.co.uk





© 2013 The University Of Sheffield


### Inkjet printer in Sheffield (MicroFab 4, piezoelectric DOD)












#### Accuracy & repeatability



PMMA on glass



© 2013 The University Of Sheffield







#### Materials & method

Group		Composition of ink			of	Pattern	Parameters of pattern		Substrate
		Solute	wt %	Solvent	printhead / μm		dx / μm	dy / μm	
PU	Ink 1	PEG <sup>1</sup>	50	DMF	60	Hexagon	0.4	0.2	977-2
	Ink 2	IPDI/BiNeo	74/1	DMF					
PEG		PEG <sup>2</sup>	5	Pure Ethanol	60	Hexagon	0.4	0.2	977-2
PMMA		PMMA	5	DMF	60	Hexagon	0.4	0.2	977-2

PU: polyurethane

PEG<sup>1</sup>: poly(ethylene glycol) Mn = 400

PEG<sup>2</sup>: poly(ethylene glycol) Mn = 20,000

IPDI: Isophorone diisocyanate

DMF: N,N-Dimethylformamide

BiNeo: Bismuth neodecanoate

PMMA: poly(methyl methacrylate)


Substrate: Carbon fibre pre-impregnated with resin (prepreg) was obtained from Cytec (CYCOM 977-2-35-12KHTS-268-300, Cytec Industries Inc., New Jersey, USA)








### Pattern – Hexagon






### Morphological analysis

#### PU dots on 977-2 pre-preg



a. Before curing



b. After curing


PU droplets are double-printed and polymerised in situ on pre-preg, and keep the printed hexagon pattern after curing cycle. (PU not subject to IP due to limited results – here used only for demonstration of printing accuracy. Synthesised in-situ from two polymer parts.)





#### Short beam shear test

- Maximum interlaminar shear stress  $(T_M)$ , each group contained 5 samples
- No damage introduced, investigation of undamaged parameters and placebo effect – postcuring effect of potentially un-crosslinked groups



Healing cycle: 177°C for 2 hours, harshest conditions

Purpose: to investigate any potential reduction of the shear strength, due to the presence of printed surface. Surprisingly, the structural integrity was improved with PMMA.


T<sub>M</sub> values of all groups are enhanced after healing cycle.





#### Interlaminar shear strength

- Maximum interlaminar shear stress  $(T_M)$  investigation
- Damage has been introduced this time in printed and virgin samples, before self-healing



**Healing cycle:** 177°C for 2 hours, harshest conditions

**Purpose:** to investigate the total reduction in shear strength due to the introduced damage and to look for the effect of self-healing. PMMA again showed improvement in properties, where reduction was initially expected due to the severe damage.

 $T_M$  values are reduced after damage. Enhancement in  $T_M$  can be seen after healing cycle, and the printed M15P specimens showed the highest  $T_M$  results.

Note: error bar represents standard deviation, n = 5 www.sheffieldcomposites.co.uk










#### SBS test continued



**Healing cycle:** 177°C for 2 hours, harshest conditions

**Purpose:** to investigate effect of self-healing on the material's stiffness. The effect achieved successfully. The printed surface noticeably increased the stiffness of the material both before and after the heat treatment.

With printed self-ameliorating agents, unidirectional fibre-reinforced plastic composite has higher stiffness than that of the virgin system.












### Mode I interlaminar fracture toughness (G<sub>IC</sub>) test




The fracture toughness, obtained by the most destructive interlaminar test, showed approximately the double increase in value both before and after self-healing for printed PMMA material. To arrest crack propagation at this level implies even stronger capability to arrest the crack in normal service levels.





# Functional gradation of properties



Sample type

Crack propagation way


G<sub>lc</sub> (fracture toughness) values of polymer printed areas are comparatively higher than unprinted areas, which means inkjet printing can be applied to delicate material design work, and manufacture property graded multifunctional materials.







# Discrete and film patterns




G<sub>Ic</sub> (fracture toughness) values of discretely printed areas have comparatively higher fracture toughness values and higher predictability than fully printed surfaces with the same amount of PMMA (20% dots = 10% film by V<sub>f</sub>). Adding more polymer to film (20% film equivalent to 40% dots) resulted in the loss of engineering predictability.








# Patterns and polymer loadings



%PMMA ↑ G<sub>Ic</sub> ↑ Repeatability ↑


www.sheffieldcomposites.co.uk







# Dynamic mechanical properties preservation




This zone is important in the machining process









# Machining quality improvement







Typical tool wear in CFRPs




Inside CFRP hole



Inside printed CFRP hole



Edge of CFRP hole



Edge of printed CFRP hole











# A plan to develop BVID detectable by SHM...

...ended up with 1J impact only in our UD

specimens



Sultan MTH, Worden K, Pierce SG, Hickey D, Staszewski WJ, Dulieu-Barton JM, Hodzic A, On impact damage detection and quantification for CFRP laminates using structural response data only, Mechanical Systems and Signal Processing 25(8): 3135-3152, 2011.












## X-ray tomography @ Southampton





Through-thickness
Slice-by-slice








## X-ray tomography @ Southampton

- System: Custom design Nikon/Metris dual source high energy micro-focus walk-in room system
- This scan used the 225kV source with and 1621 PerkinElmer cesium-iodide detector
- To enhance contrast a Mo target was used and peak voltage was set at 55kV, with no pre-filtration
- The current was set at 157uA (8.6W) and the panel brought forwards so that the source-imaging distance was ~700mm. At this power, the focal spot is spread slightly to prevent melting of the target however, since the voxel size at this magnification was 7.6microns, we could afford to gain flux at the expense of focal spot size, without affecting the resolution of the reconstruction.
- 3142 projections were taken over the 360 degree rotation, with 4 frames per projection being averaged in order to improve signal to noise
- Exposure time of each projection was 354ms and the gain set to 30dB
- To reduce the effect of ring artefacts, shuttling was used with a maximum displacement of 5 pixels
















#### In nuce

(In pursuing the original task: to quantify the SH effect)

- Can we accurately print thermoplastics in AE accredited CFRPs?
- Are there compatible SH polymers in the incompatible families? □
- Are structural static and dynamic properties preserved? □
- Is damage tolerance improved? □□
- Are discrete patterns more desirable? □
- Are shear properties improved?
- Is there improvement after  $2^{nd}$  thermal treatment?  $\square$
- Is machining qualitatively improved? □
- Did we manage to avoid adding any parasitic weight? □
- Did we conform to the existing supply chain?
- Did we increase the value of the product?
- Did we pioneer a new improved system?



With massive thanks to







# International roadmaps for IJPCs

#### Sheffield, Bristol, South Carolina (McNair) and Clemson:

- R1: manufacturing of novel IJPCs
  - (Smith, Hodzic, Scaife, Tarbutton, van Tooren)
- R2: embedding novel sensors in IJPCs
  - (Giurgiutiu, Tarbutton, Smith, Hodzic)
- R3: grafting novel polymers for IJPCs
  - (Luzinov, Kornev, Smith)
- R4: watermark composites
  - (Smith, van Tooren, Majumdar)
- R5: multiscale ultrasonic inspection in woven IJPCs
  - (Banerjee, Giurgiutiu, Smith, Hodzic, van Tooren)
- R6: developing FEA from x-ray tomography of IJPCs
  - (Pinna, Deng, Majumdar, Smith, Hodzic, van Tooren)
- R7: validation of damage models in IJPCs using SHM and 3D NDT
  - CSIC (Hodzic, Smith, Pinna), DRG (Worden, Manson) from Sheffield and NDT (R. Smith) from Bristol – white paper submitted to AFOSR
- R8: machining of IJPCs, influence on durability
  - (Hodzic, Scaife, Pinna, Smith)
- R9: integration of R1-8





# Innovation and Research Manufacture/Characterization/Certification

#### Research

- Advanced Materials and Structures
- Design
- Development
- Testing
- Commercialization
- Response to
  - extreme conditions
  - lightning
- Life Cycle
- Monitoring
- Remediation and Maintenance
- Systems design
- > Fuel Cells/Power Sources
- Cyber security
- Supply Chain
- Sustainability
- Optimization
- Global Regulated Business Strategy

- Center for Mechanics, Materials, and Non-Destructive Evaluation
- Laboratory for Active Materials and Smart Structures
- Center for Friction Stir Processing, NSFI/UCRC
- Virtual Test Bed
- Condition-Based Maintenance Research Center
- Lightning Response Laboratory
- HetroFoaM Center
- Solid Oxide Fuel Cell Center
- Strategic Approaches to the Generation of Electricity
- May 2014: Advanced Composite Material Research Laboratory







# FW: NDT at high frequencies


#### Prof. Robert Smith

- 3D Characterisation of composite materials
  - Ultrasonic response
  - Inversion methods give actual material properties
- Fibre vector maps
- Fibre volume fraction
- Porosity
  - Frequency response
  - Distinguish between types












Out-of-plane slice







**Vector Map** 



**Porosity**